



www.hurricaneaquasports.com

Owner's Manual

Please visit our website for warranty registration

Hurricane Kayaks has been designing and building beautiful, lightweight, thermoformed kayaks from Trylon for over a decade. During this time we have made thousands of paddlers happy with our kayaks. Please take a few moments to read this manual and become acquainted with your boat and its features. We are happy that you have chosen Hurricane Kayaks and we know that you will have a lifetime of enjoyment on the water.

Transport

Hurricane recommends transporting your kayak on a car-top rack system specifically designed for this purpose. Your kayak will remain most stable when it is loaded upside down and tied down securely.

Storage

We recommend storing your kayak on a cushioned surface in a dry, shaded area either upside down or on its side. Cockpit covers are also recommended to maintain a clean, dry cockpit.

Do not place heavy objects on top of your kayak in storage!

Cleaning

- Always rinse your kayak with fresh water after every salt water adventure.
- If necessary, use a mild soap and water solution to remove pond scum and other residual matter after each trip.
- Use denatured alcohol to remove stubborn scuff marks.
- **NEVER** use solvent cleaners!

Repair

Trylon (ABS) can easily be repaired following these instructions.

To repair a crack –

1. Drill a stop at each end of the crack with a small drill bit to prevent the crack from growing.
2. Clean the area to be repaired with denatured alcohol.
3. Apply epoxy liberally to both sides of the crack . The epoxies we recommend are Devcon Plastic Welder (available at most hardware stores) or Marine Tex (available at West Marine).

Seat Adjustment

The seats in the Santee 100LT Santee 116 & 116 Sport, Santee 126, Santee 135, Santee 140 Tandem, Excursion 128, Expedition 140 & 140 Sport, and the Tampico 140 L can be adjusted to achieve the most comfortable fit for each paddler.

- *To raise or lower the seat back* – tilt the top of the seat forward and gently pull up (or push down). When the desired height position is attained, tilt the top of the seat backwards to lock into position. The orange ball on the seat back can be slipped into the bungee on the underside cockpit to hold positioning.
- *To raise the thigh support* – pull the orange ball on each side of your seat until the desired level of support is reached. Use the clam cleats to lock the cord into position.
- *To achieve more aggressive back support* – simply pull the end of the 1 inch wide black webbing which supports the back rest.

If you own a Santee 140 Tandem – you may move the front seat to the center position by unscrewing the poly knobs on each side of the forward section of the cockpit; slide the seat into the desired position, and replace the poly knobs.

Limited Warranty

All Hurricane Kayaks are covered under warranty against any defect in materials and workmanship for a period of three years from the date of purchase. This warranty is limited to the original owner and is only in effect if the warranty registration card is returned or the kayak is registered online at www.hurricaneaquasports.com.

CONDITIONS: Hurricane Kayaks will repair or replace all items returned under warranty at its own discretion. Hurricane Kayaks is the sole judge of warrantability. The customer pays for all return transportation, freight, and/or packaging charges for warranty claims. Kayaks used commercially are covered under warranty for a period of one year.

If a product is deemed to be blemished and is sold as a blemished quality product, the warranty is still in place with the exception of the blemish itself. The following are never covered under warranty: freight damage, improper storage, improper use, abuse, towing, normal wear and tear, and color fading due to UV rays.

What do I do if I experience a problem?

Contact your nearest dealer.

Your local Hurricane Kayaks dealer can order any spare parts that you may need.